

S61N ANNUNCIATOR PANEL LEGENDS

MASTER WARNING PANEL

1 #1 GENERATOR 25-0021-549	10 #2 GENERATOR 25-0021-555	19 # 1 ENG CHIP DET 25-0021-968
2 DC GENERATOR 25-0021-527	11 RECTIFIER 25-0021-544	20 #2 ENG CHIP DET 25-0021-969
3 FWD FUEL LOW 25-0021-530	12 AFT FUEL LOW 25-0021-524	21 CTR TANK OVERFLOW 25-0021-1862
4 FWD FUEL BYPASS 25-0021-529	13 AFT FUEL BYPASS 25-0021-523	22 SPARE 25-0021-554
5 PRI SERVO PRESS 25-0021-562	14 AUX SERVO PRESS 25-0021-525	23 CHIP DET MAIN 25-0021-1209
6 TRANS OIL PRESS 25-0021-558	15 TRANS OIL HOT 25-0021-557	24 CHIP DET INTMED 25-0021-1983
7 #1 ENG OIL PRESS 25-0021-534	16 #2 ENG OIL PRESS 25-0021-535	25 CHIP DET TAIL 25-0021-1984
8 #1 INLET ANTI-ICE 25-0021-535	17 #2 INLET ANTI-ICE 25-0021-537	26 #1 IGV ANTI-ICE 25-0021-2050
9 SPARE 25-0021-554	18 SPARE 25-0021-554	27 #2 IGV ANTI-ICE 25-0021-2051

S61N ANNUNCIATOR PANEL LEGENDS

AUXILLIARY WARNING PANEL

1 #1 ENG ANTI-ICE ON 25-0021-548	6 #2 ENG ANTI-ICE ON 25-0021-552
2 #1 PITOT HEAT 25-0021-551	7 #2 PITOT HEAT 25-0021-553
3 COMPASS FAIL 25-0021-1187	8 BIM PRESS 25-0021-1845
4 LH LDG LT EXT 25-0021-533	9 RH LDG LT EXT 25-0021-543
5 HEATER HOT 25-0021-532	10 TAIL TAKE OFF 25-0021-1161

ADVISORY PANEL

1 EXT PWR ON 25-0021-528	6 NOSE DOOR OPEN 25-0021-538
2 PARKING BRAKE ON 25-0021-541	7 ROTOR BRAKE ON 25-0021-545
3 CARGO DOOR OPEN 25-0021-526	8 PASS DOOR OPEN 25-0021-540
4 SPARE 25-0021-554	9 SPARE 25-0021-554
5 DC GEN MOTORIZED 25-0021-580	10 SPARE 25-0021-554